

Bloating Buffers

Geoff Huston

APNIC Labs

The Evolution of Speed

1980's

- TCP rates of Kilobits per second

1990's


- TCP rates of Megabits per second

2000's

- TCP rates of Gigabits per second

2010's

- TCP rates of Gigabits per second



The Evolution of Speed

1980's

- TCP rates of Kilobits per second

1990's



- TCP rates of Megabits per second

2000's

- TCP rates of Gigabits per second


2010's

- TCP rates of Gigabits per second



Today

- Optical transmission speeds are now edging into Terabit capacity
- But peak TCP session speeds across the network are not keeping up
- Why not?



TCP is the Internet

- The Transmission Control Protocol is an end-to-end protocol that creates a reliable stream protocol from the underlying IP datagram device
- This single protocol is the “beating heart” at the core of the Internet
- TCP operates as an adaptive rate control protocol that attempts to operate **efficiently** and **fairly**

TCP Design Objectives

To maintain an average flow which is **Efficient** and **Fair**

Efficient:


- Minimise packet loss
- Minimise packet re-ordering
- Do not leave unused path bandwidth on the table!

Fair:

- Do not crowd out other TCP sessions
- Over time, take an average $1/N$ of the path capacity when there are N other TCP sessions sharing the same path


It's a Flow Control process

- Think of this as a multi-flow fluid dynamics problem
- Each flow has to gently exert pressure on the other flows to signal them to provide a fair share of the network, and be responsive to the pressure from all other flows



TCP Control

TCP is an **ACK Pacing** protocol



Data sending rate is matched to the ACK arrival rate


TCP Control

- Ideally TCP would send packets at a fair share of available network capacity. But the TCP sender has no idea what “available network capacity” means.
- So TCP uses ‘rate adaptation’ to probe into network, increasing the sending rate until it is ‘too fast’
- Packet drop is the conventional signal of ‘too fast’

"Classic TCP" - TCP Reno

- Additive Increase Multiplicative Decrease (AIMD)
 - While there is no packet loss, increase the sending rate by one segment (MSS) each RTT interval
 - If there is packet loss decrease the sending rate by 50% over the next RTT Interval, and halve the sender's window
- Start Up
 - Each RTT interval, double the sending rate
 - We call this "slow start" – probably because its anything but slow!!!

The Classic TCP Picture



TCP and Buffers - the Theory

- When a sender receives a loss signal it repairs the loss and halves its sending window
- This will cause the sender to pause for the amount of time to drain half the outstanding data in the network
- Ideally this exactly matches the amount of time taken for the queue to drain
- At the time the queue is drained the sender resumes its sending (at half the rate) and the buffer has fully drained
- For this to work, the queue size should equal the delay bandwidth product of the link it drives

TCP and Buffers - the Theory

- When a sender receives a low signal it repairs the loss and halves its sending window
- This will cause the sender to pause for the amount of time it takes to drain half the outstanding data in the queue
- Ideally this exactly halves the delay for the queue to drain

All this works with an assumption of a single queue and a single flow

- When the buffer is drained the sender resumes its sending at half the rate, and the buffer has fully drained
- For this to work, the queue size should equal the delay bandwidth product of the link it drives

TCP and Buffers


The rule of thumb for buffer size is:

$$\text{Size} = (BW \cdot RTT)$$

“High Performance TCP in ANSNET”
Villamizar & Song, 1994

TCP and Buffers

Too Small: The queue drains and the sender operates below bottleneck speed – so the link is under-used



TCP Evolution


- The TCP packet format is invariant
- But the control algorithm can vary
- What defines a “better” control algorithm?
 - Be no less ‘aggressive’ than everyone else
 - And try to exploit what others are not
 - But don’t destroy the environment (network)

Evolutionary Efforts


- There have been many efforts to alter RENO's flow control algorithm
- In a loss-based AIMD control system the essential parameters are the manner of rate increase and the manner of loss-based decrease
 - For example:
 - MuTCP behaves as if it were N simultaneous TCP sessions: i.e. increase by N segments each RTT and rate drop by $1/N$ upon packet loss
- What about varying the manner of rate increase away from AI?

Enter CUBIC

- CUBIC is designed to be useful for high speed sessions while still being 'fair' to other sessions and also efficient even at lower speeds
- Rather than probe in a linear manner for the sending rate that triggers packet loss, CUBIC uses a non-linear (cubic) search algorithm



CUBIC and Queue formation



CUBIC assessment



- Can react quickly to available capacity in the network
- Tends to sit for extended periods in the phase of queue formation
- Can react efficiently to long fat pipes and rapidly scale up the sending rate
- Operates in a manner that tends to exacerbate 'buffer bloat' conditions

From 1 to N - Scaling Switching

- This finding of buffer size relates to a single flow through a single bottleneck resource
- What happens to buffers with more flows and faster transmission system?


Flow Mixing

- If 2 flows use a single buffer and they resonate precisely then the buffer still needs to be delay-bandwidth size
- If they are precisely out of phase the common buffer requirement is halved



Smaller Buffers?

- What about the case of N de-synchronised flows?

$$\text{Size} = (BW \cdot RTT) / \sqrt{N}$$


Assuming that the component flows manage to achieve a fair outcome of obtaining $1/N$ of the resource in a non-synchronised manner, then the peak buffer resource is inversely proportionate to the square root of N

The Role of Buffers

- Buffers in a network serve two essential roles:
 - smooth sender burstiness
 - Multiplexing N inputs to 1 output

Sender Pacing

- Distribute cwnd data across the entire RTT interval
- Removes burst adaptation pressure on network buffers

Tiny Buffers?


If all senders 'paced' their sending to avoid bursting, and were sensitive to the formation of standing queues then we would likely have a residual multiplexing requirement for buffers where:

$$B \geq O(\log W)$$

where W is the average flow window size

Why is this important?

- Because memory speed is not scaling at the same rate as transmission or switching
- Further capacity and speed improvements in the network mandate reduced memory demands within the switch




Switching Chip Design TradeOffs

- On-Chip memory is faster, but limited to between ~16M to ~64M
- A chip design can include an interface to external memory banks but the memory interface/controller also takes up chip space and the external memory is slower
- Between 20% to 60% of switch chip real estate is devoted to memory / memory control
- Small memory buffers in switch design allows for larger switch fabric implementations on the chip

Switch Design

Barefoot Tofino ASIC Architecture


- BFN-T10-018D from Tofino family
- 1.8Tbps Single Chip Ethernet Switch
- 2 Pipes @0.9 Tbps
- P4-programmable pipeline
- Single 16 MB Unified Packet Buffer
- Inband Network Telemetry (INT)



Optimising Flow State

- There are three 'states' of flow management:
 - **Under-Utilised** – where the flow rate is below the link capacity and no queues form
 - **Over-Utilised** – where the flow rate is greater than the link capacity and queues form
 - **Saturated** – where the queue is filled and packet loss occurs
- Loss-based control systems probe upward to the Saturated point, and back off quickly to what they guess is the Under-Utilised state in order to let the queues drain
- But the optimal operational point for any flow is at the point of state change from Under to Over-utilised, not at the Saturated point


RTT and Delivery Rate with Queuing



How to detect the onset of queuing?

- By getting the network say when queues are forming?

Explicit Congestion Notification



Explicit Congestion Notification

- Sparse signal (single bit)
- Both hosts and routers need to be ECN aware
- IP level marking requires end host protocol surgery at both ends:
 - Receivers need to reflect ECN bits
 - Senders need to pass IP ECN up to the TCP session

ECN Issues

- It would be good if everyone did it!
- But they don't all do it, which means that hosts cannot rely on ECN as the only means of congestion control
- What's the value of partial adoption of ECN?

How to detect the onset of queuing?

- ~~By getting the network say when queues are forming~~

OR

- By detecting the onset of queue-based delays in the measured RTT

Flow Control Evolution

- Current flow control systems make small continual adjustments every RTT interval and a massive adjustment at irregular intervals
 - As the flow rate increases the CA adjustments of 1 segment per RTT become too small
 - Rate halving is a massive response


OR

- We could use a system that only made periodic adjustments every n RTT intervals based on delay probing
 - And set the adjustment to be proportionate to the current flow rate

BBR Design Principles

- Pace the sending packets to avoid the need for network buffer rate adaptation
- Probe the path capacity only intermittently (every 8th RTT)
- Probe the path capacity by increasing the sending rate by 25% for an RTT interval and then drop the rate to drain the queue:
 - If the RTT of the probe interval equals the RTT of the previous state then there is available path bandwidth that could be utilised
 - If the RTT of the probe rises then the path is likely to be at the onset of queuing and no further path bandwidth is available
- Do not alter the path bandwidth estimate in response to packet loss

Idealised BBR profile




sending rate

network queues

BBR Politeness?

- BBR will probably not constantly pull back when simultaneous loss-based protocols exert pressure on the path's queues
- BBR tries to make minimal demands on the queue size, and does not rely on a large dynamic range of queue occupancy during a flow




Our Environment...

- A diverse mix of e-2-e TCP control protocols
CUBIC, NewRENO, LEDBAT, Fast, BBR
- A mix of traffic models
Buffer-filling streamers, flash bursts, bulk data
- A mix of active queue disciplines
RED, WRED, CODEL, FQ, none
- A mix of media
Wire line, mobile, WiFi
- A mix of buffer size deployments
- Sporadic ECN marking

Protocol Darwinism?

What “wins” in this diverse environment?


- **Efficiency** is perhaps more critical than **Fairness** as a “survival fitness” strategy
- I suspect that protocols that make minimal assumptions about the network will be more robust than those that require certain network characteristics to operate efficiently
- Protocols that operate with regular feedback mechanisms appear to be more robust than irregular “shock” treatment protocols



What is all this telling us?

- We actually don't know all that much about fine-grained behaviour of large scale high capacity switching systems.
- Some of our cherished assumptions about network design may be mistaken
- Moving large data sets over very high speed networks requires an entirely different approach to what we are doing today
- The Internet still contains a large set of important unsolved problems

That's it!



Questions?